




PRESTIGE PADDED COLLAR



End of Buckle

PRODUCT SIZE:

Product sizes for all collars in the Prestige Padded Collar range are measured from the end of the buckle to the central collar hole.

Measuring from the middle hole allows the the collar to be adjusted up and down as needed. Increasing or decreasing the size by 5cm as required.

Collar Size	FITS NECK SIZES	
	FROM	TO
14"/36cm	33.5cm	38.5cm
16"/41cm	38.5cm	43.5cm
18"/46cm	43.5cm	48.5cm
20"/51cm	48.5cm	53.5cm
22"/56cm	53.5cm	58.5cm
24"/61cm	58.5cm	63.5cm
26"/66cm	63.5cm	68.5cm
28"/71cm	68.5cm	73.5cm
30"/76cm	73.5cm	78.5cm

* Size Chart to be used as a guide only.

Neck Size measurements include a (+/- 2.5cm) tolerance for a comfortable fit.

Central Collar Hole